




1	PN 1703	Seat Top
2	PN 1923	Seat Carriage (left and right)
3	PN 1724	Top Seat Roller x 2
4	PN 1302	Seat Roller Spacer x 6
5	PN 1725	Bottom Seat Roller x 2
6	PN 125	Seat Roller Washer x 2
7	PN 1209	Seat Roller Nut x 4
8	PN 1208	Bottom Seat Roller Bolt x 2
9	PN 1246	Seat Top Lock Washer x 4
10	PN 1207	Seat Top Screw x 4
11	PN 1211	Top Seat Roller Bolt x 2
12	PN 1707	Monorail w/ Track & Hanger Assy.
13	PN 1762	Stainless Track with tape
14	PN 1175	Rear Leg
15	PN 119	Rubber Foot x 4
16	PN 1008	Rear Bumper
17	PN 1201	3/4" Button Head Screw
18	PN 1213	1/4" Nut
19	PN 1253	1/2" Button Head Screw
20	PN 1006	Top Front Bumper
21	PN 1217	Acorn Nut x 2
22	PN 1251	Poly Rivet x 2
23	PN 1103	Monorail Bolt Tube
24	PN 1007	Bottom Front Bumper
25	PN 1102	Monorail Hanger x 2
26	PN 1204	Monorail Hanger Bolt x 2
27	PN 1169	Left Foot Bracket
28	PN 1171	Right Foot Bracket
29	PN 1720	Flex foot / Stretcher Cover W/ Screws
30	PN 1017	Flex foot x 2
31	PN 1235	1/4" Nylock Nut x 4
32	PN 1501	Foot Strap x 2
33	PN 1210	Foot Bracket Screws - Allen Key Head x 8
34	PN 1244	3/8" Nylock Nut x 13
35	PN 1227	Short Toe Piece Screw x 6
36	PN 1228	Long Toe Piece Screw x 2
37	PN 1229	Toe Piece Washer x 2
38	PN 1212	Nylock Nut Toe Piece x 8
39	PN 1792	Frame Lock
40	PN 1144	Frame Lock Axle
41	PN 1178	Box Frame
42	PN 1104	S.C.A.M. x 2
43	PN 1731	Shock Cord
44	PN 1310	Shock Cord Pulley Axle Spacer x 4
45	PN 1756	Traveling Pulley
46	PN 1024	Chain Idler Pulley x 2
47	PN 1206	Traveling Pulley Screws x 2
48	PN 1249	1/4" Nylock Jam nut x 2
49	PN 285	Chain Connector x 2

50	PN 1754	Handle Hook
51	PN 1965	Chain (with Swivel & Connectors & Sprocket)
52	PN 1165	Flywheel Axle
53	PN 1300	17mm Bearing
54	PN 1739	14 Tooth Sprocket
55	PN 1013	R8 Bearing Rubber Cup
56	PN 232	R8 Bearing
57	PN 1010	Bearing Cover
58	PN 1011	Shock Cord Pulley x 4
59	PN 1130	Shock Cord / Idler Pulley Axle x 3
60	PN 1025	Monitor Arm
61	PN 1974	PM3 Monitor
62	PN 1279	Generator Cover Screw x 2
63	PN 1030	Generator Housing Cover
64	PN 1402	PM3 Sensor Coil
65	PN 1029	Generator Housing Base
66	PN 1533	Technique Label
67	PN 1169	Chain Guide Bracket Left
68	PN 1168	Chain Guide Bracket Right
69	PN 1003	Chain Guide
70	PN 1268	Monitor Arm Bolt 3.5" long
71	PN 1271	3/8" Nut
72	PN 1910	Log Card
73	PN 1224	Monitor Arm Bolt 4" long
74	PN 1308	Castor Wheels
75	PN 1309	Castor Stop
76	PN 1935	Front Foot Assembly
77	PN 1173	Front Leg Long
78	PN 1172	Front Leg Short
79	PN 1009	End Cap
80	PN 1131	End Cap Hook
81	PN 1031	Flywheel Cover Back
82	PN 1912	Outlet Perf w/connectors
83	PN 1942	Flywheel Cover Front Assembly
84	PN 1033	Damper
85	PN 1274;	1275 Outlet Perf Connector Screw & Nut
86	PN 1035	Perf Connector Screw Side
87	PN 1036	Perf Connector Nut Side
88	PN 1278	Wave Washer
89	PN 1034	Hub Cap
90	PN 1276	Flywheel Cover Bolt x 4
91	PN 1273	Damper Screw
92	PN 1940	Flywheel Assembly w/Magnet
93	PN 1012	17mm Bearing Rubber Cup
94	PN 1040	Handle W/ Grips
95	PN 244	Handle U Bolt
96	PN 1205	Lock Washer x 10
97	PN 1105	Hanger Bolt Tube x 2
98	PN 1203	Hanger Bolt x 2
99	PN 1534	Hub Cap Label
100	PN 1232	Fender Washer x 8
101	PN 1303	Traveling Pulley Spacer
102	PN 1305	Idler Pulley Spacer x 2